

INSTRUCTION MANUAL DAT WIFI



Description

- 1.Back panel
- 1.Control panel
- 2.Temperature control
- 3.Power switch
- 4.Front panel
- 5.Castors



Important safeguards

- The product is for household use only
- The item should be used only as intended
- Check item carefully before use. Do not switch on heater with defects or damaged cord.
- Placing of the item in water is forbidden.
- Plug in the item only to AC source.
- The appliance should be connected to the same voltage as pointed on the rating label and package
- The heater could be plugged in only grounded socket.
- Do not use non-standard power supply.
- Before plug in the heater, make sure that it is switched off.
- Do not use item outdoors.
- Protect the product from impacts of the sharp corners, high humidity.
- Do not touch heater with wet hands.
- If there is water on the surface of the heater, plug it out immediately.
- If the heater falls in water, plug it out immediately. It is forbidden to put hands in the water.
- Before next use the item should be checked by specialist.
- Always plug the item out after use, before cleaning or if you find the defects.
- The heater can't be carried by the cord.
- When you switch off the heater keep your hand on the plug and pull it, do not pull the cord.
- Do not wrap the cord around the appliance after the use.
- Flatten smoothly the cord when you do not use the heater.
- The cord could be changed only in service center.
- Only original spare parts could be used for repair.
- This appliance is not intended for use by persons(including children) with reduced physical,sensory or metal capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Safety instructions


- The appliance should be connected to the same voltage as pointed on the rating label and package.
- Do not plug the item in before its not wall mounted or set on castors.
- Do not cover the item when it is operating.
- Avoid placing foreign objects in air vents.
- It is forbidden to pull and twist the cord.

Before use


- Take the heater out of the box
- Remove the packing material
- Check the installation parts

Installation

- The panel convactor heaters should be wall-mounted. Some items can be also stand with feet.
- Mount feet on the baseboard in accordance with scheme G1.
- For wall mounting study scheme G2.
 - a.Uninstall the bracket from the body,see the image1
 - b.Drill the holes at each sides on the wall,then insert the plastic expanded plugs within, Fix the bracket in the wall with screw,see the image2
 - c.Fit the heater into suitable position ensuing that the holes align with bracket.see image3
 - d.Tight the screw on the top of bracket to catch steady,image4
- Pay attention to the position of the convector with regard to other objects.
- It is forbidden to place item under the socket.
- The convector has got IP24 degree of protection
- If you place item in bathroom, avoid ingress of water on the surface.



G1



G 2

Use of the item

- Place the heater on flat stable surface
- Switch thermostat knob in off position
- Plug the heater in
- By turning the handle of thermostat clockwise or counter clockwise set the required temperature. For fast heating of the room set the thermostat handle at maximum level. As soon as required temperature will be reached, turn thermostat handle counter clockwise until you hear click. The heating elements will switch off. Indicator light will be also off.
- Convector will automatically switch on when temperatures decreases and it will automatically switch off when temperature increases. The comfortable ambient temperature is maintained.
- If the appliance is not used for a long time--switch it off with power switch and plug the item out
- Attention! Do not cover the product! Convector should not be place under shower or in swimming pool

TOUCH SCREEN AND REMOTE CONTROL OPERATION

Insert the plug in a suitable power socket.

The touch screen buttons located on the product correspond to the remote control functions:

1. display
2. temperature
3. mode
4. timer
5. power



Power

When the product is on, press “power”, . the upper part of the display shows temperature.

The heater is working at low power heating conditions.

Mode

Press “mode” to regulate low $\{\}$, or high temperature power. $\{\{\}$

Temperature



Press  button to select the desired temperature from a range of 15°-35°C.

Timer

The timer button can be set to start or stop the appliance at the desired time, with a time interval between 1 hour and 24 hours.

Operating sound

The appliance emits a beep upon each operation setting.


Cleaning

- Before cleaning the item wait when it cools down and plug out
- Do not use abrasives and solvents. Wipe the product with soft wet cloth
- It is necessary to remove dust from the surface regularly
- Washing the item and placing it in water is forbidden!
- If you are going not to use heater for long time, wipe it surface and put the item in color box.
- It should be placed in dry ventilated room. Avoid high humidity and mechanical impact on the item

Details	PN1000AL	PN1500AL	PN2000AL
Voltage	220-240V	220-240V	220-240V
Frequency	50Hz	50Hz	50Hz
Power	500/1000W	750/1500W	1000/2000W

WIFI Function

1. Use your phone to scan the QR code below or search “Tuya Smart” in Application on market to download and install the App.
2. Select your country code, enter the cellphone number and tap “Get” to get a message containing verification on code.
3. Enter the verification on code in the message and tap “Login” to login the App.
4. Go to the App, tap “add device” at the bottom, as shown in the picture 1




Pic 1

5. There are two connection on methods for the App (hotspot mode and quick connect mode). The quick connect mode is the default mode. Users could tap the upper right corner to switch the connection on method to hotspot mode.
 - a. For quick connect mode, please make sure the device's instructor light quickly flashes
 - b. For hotspot mode, please make sure the device's instructor light slowly flashes
 - c. If the light is not flashing as the status as above described, please long

press the device's reset button  for 5 seconds or longer until it flashes correctly as shown in the picture below,

6. Select the Wi-Fi, enter password and tap “Next”, as shown in the picture 2 below,

For quick connect mode, the App interface will go through the changes during the network configuration on processes shown in the picture 3, Picture 4 shows the interface when the device is connected successfully.



Pic 2

Pic 3

Pic 4


7. After the device is connected successfully, tap “Devices” at the bottom. The device name shows in the list in the picture 5. Tap it to enter the control panel of the smart socket.

Remarks:


When device is online, there will be a green dot at the front of the device icon;

When the device is offline, the dot will be grey;


If is the device shared by others, there will be double loop.



Pic 5



Pic 6



Pic 7

8. "My profile" is where users could manage personal information. The key information is as follows see picture 6:

follows see picture 6:

- a. Personal information: including account name and cellphone number
- b. Information of shared devices
- c. Message center
- d. Entry to submit feedback
- e. F.A.Q

f. Phone binding: if you sign in with social network account, you could bind your phone number with your account

g. About

9. Add sharing: As shown in the picture, users could type in a new member's cellphone number and share the device with him. The new member could control the device with his own account, see picture 7

Attention: never leave heater unattended!

The importer retains his right to make changes in appearance and completeness of the item without preliminary notification to the customer.

The item is for household use only.

Attention! The manufacturer does not assume any liability for any damage caused directly or indirectly by not following this instruction manual, general safety rules, or interference in the construction of the product



This marking indicates that this product should not be disposed with other

household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

<https://datheating.eu>